







Installation instruction for low, medium and high intensity obstacle lights


092648 00






















## Warning:

Make sure that the mains power supply is disconnected before you start the electrical installation.

Make sure you comply with the (pre)conditions for electrical systems in explosive atmospheres.



## Note:

Make sure that the photocell has the clearest possible view on the environment. Make sure that the photocell points away from obstacles, such as structures, wind turbine blades, light sources and other equipment.